

Seal and protect polished paintwork from environmental contaminants with a durable high-gloss shine.

TOP TIPS

- Always use the recommended microfibre cloths with **Aqua Wax** and **High Definition Wax**. They have been carefully selected to ensure ease of use and to achieve the best finish
- Once applied leave **Extra Gloss Protection** for as long as possible to allow the resins to continue to cure and work even better
- All Autoglym waxes and sealants offer impressive protection and will repel water. Once rainwater stops beading from the paintwork, it is time to re-apply

SUPER FAST SOLUTION



1 Wash the vehicle in the normal way with **Bodywork Shampoo Conditioner** and hose down.



2 Spray **Aqua Wax** evenly over all surfaces except the windscreen.



3 Use one of the supplied microfibre cloths to spread the wax, then the other one to buff to a high gloss.

CONCOURS FINISH



1 Using one of the damp red applicators supplied, apply wax evenly in a light circular motion to a panel at a time.



2 When you have applied wax to the whole car, leave to cure for around 15 minutes or more on a cold day.



3 Buff to a high gloss with the red finishing cloth supplied, turning it frequently to avoid build-up.

LIQUID SEALANT



1 Pour **Extra Gloss Protection** onto the **Perfect Palm Applicator**. Do not pour liquid onto the car.



2 Use a light pressure to apply liquid to the car and leave to dry thoroughly for one to two hours to allow resins to cure.



3 Buff to a deep shine with the **Hi-Tech Finishing Cloth** turning it regularly. Avoid application on to the glass.